




MODEL CS-41




aace[™]

**INSTRUCTIONS
HOW TO USE**

IMPORTANT: KEEP THIS INSTRUCTION BOOKLET IN THE
PLACE PROVIDED ON THE CHILD RESTRAINT

DO NOT USE THIS CHILD RESTRAINT UNTIL YOU HAVE READ AND UNDERSTOOD THE INSTRUCTIONS IN THIS USER GUIDE AND IN YOUR VEHICLE OWNERS MANUAL



Please keep this Instruction Booklet in the storage area under the seat for future reference.

Distributed by: Allison AU Pty. Ltd.
ACN: 642 240 140
Unit 1, 35 Lyn Parade, Prestons,
NSW Australia 2170

For after-sales & warranty service, contact:
1800 951 070 customerservice@allisonau.com.au

Contents

Quick Reference	3
WARNING	4
Features	5 & 6
IMPORTANT INFORMATION	7
After this Booster Seat	8
Shoulder Height Labels	9
Headrest Position	10
Fitting Vehicle Belt	11
CHECKLIST	12
Seat Bottom Adjustment	13
Extra Side Impact Protection	14
Removing and Refitting Cover	15
Fitting and Removing Cupholder	16
Care, Maintenance and Storage	17
Accessories and Spare Parts	18

Quick Reference

IMPORTANT: Also read the detailed instructions that follow this quick reference

SIP correctly adjusted
page 14

Headrest adjusted to suit the child's height.
page 10

Sash belt must make good contact with the child's chest.
page 11

Vehicle Belt must always be securely latched.
page 12

Lap belt passes over the child's upper thighs, not across the stomach.
page 11

Both Lap and Sash belt pass under the armrest.
page 11 & 12

No heavy, sharp objects or hot liquids in the cupholder.
page 16

Suitable for children from approximately 4 years of age to approximately 8 years. See page 7 for more detailed information.

⚠ WARNING

- DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR
- Use the restraint exactly as shown in the Instructions.
- Supervision of children is needed because they may be able to undo buckles.
- The lap part of the seatbelt must be firmly across the thighs and the sash strap fitted diagonally across the chest and shoulder.
- DO NOT USE THIS RESTRAINT WITHOUT THE COVER.


THIS RESTRAINT MUST BE USED IN CARS WITH FORWARD-FACING SEATS WITH A LAP-SASH SEATBELT. THIS BOOSTER SEAT IS NOT SUITABLE FOR USE WITH A CHILD HARNESS.

NOTE: The warnings on this page are those required for this type of child restraint by the Australian and New Zealand Standard AS/NZS 1754.

Other warnings specific to this child restraint will be found throughout these instructions.


Features - Front View

HOW TO USE



Features - Back View

HOW TO USE




Important Information

- This Child Restraint is: To be used with a lap-sash seatbelt by a child whose shoulders are above the lower shoulder height marker with head restraint in the lowest position (approximately 4 years of age) until the child's shoulders reach the upper shoulder height marker with the head restraint in highest position (approximately 6 to 8 years of age).
- Continue to use this booster seat until the child reaches this limit. Children are safest in a booster seat until their shoulders reach the upper shoulder height marker of the booster seat.
- Do not use this restraint until child's shoulders are above the lower shoulder height marker with the head restraint in the lowest position.
- If the knees do not bend in front of the vehicle seat cushion continue to use a booster seat.
- Ensure that children have adequate ventilation and shade when in the vehicle.

After this Booster Seat

After your child has outgrown this booster seat they will be big enough to sit on a vehicle seat without a child restraint.




IMPORTANT: If the knees do not bend in front of the vehicle seat cushion continue to use a booster seat.




Shoulder Height Labels

Shoulder Height Label: this booster seat is rated as suitable for children from approximately 4 years to 8 years. The exact sizing is determined by the shoulder height label.

If the child's shoulders are above the dotted line when the headrest is fully up, do not use the booster seat.




If the child's shoulders are below the dotted line when the headrest is fully down, do not use the booster seat.



Headrest Position

When a child is sitting on the booster seat with their back firmly up against backrest, the top of their shoulders should be just under the bottom of the headrest.


Adjust the headrest height if necessary.



Headrest Adjustment

Squeeze headrest release lever until locking mechanism disengages, raise or lower headrest as required.

As the headrest rises the width of the sides will automatically increase.




Fitting Vehicle Belt

Place child on seat. Check headrest height and adjust if necessary. See page 10.

1. Pass sash belt through the guide under the headrest.
2. Connect the vehicle belt. Check that it is securely engaged.
3. Ensure the belt is not putting pressure on the child's neck and can slide freely through the guide.
4. Ensure the sash belt has good contact against the child's chest.
5. Belts must pass under the armrests and across the child's upper thighs.

IMPORTANT: The lap belt must not be over the child's stomach. In the event of a crash or sudden stop a lap belt moving into a child's stomach can cause serious injury.

ALWAYS USE THE SASH GUIDE



⚠ WARNING

A SASH BELT UNDER THE ARM OR BEHIND THE BACK IS DANGEROUS

Checklist

CORRECT VEHICLE BELT PATH

There are labels showing the correct vehicle belt path.

BOOSTER SEATBELT PATH
ALWAYS USE THIS SASH GUIDE

Belts must pass under the armrests

Engage vehicle buckle securely

Sash belts must pass through the red guide in the headrest

BOOSTER SEATBELT PATH

⚠ WARNING
DO NOT LEAVE CHILDREN UNATTENDED IN THE CAR

Seat Bottom Adjustment

The seat bottom can be pulled forward to suit bigger children.



To adjust:

Reach under the seat pad, locate the release lever, press this upwards.

Slide the seat pad forward or back as required.

There are three positions for the best fit.

Only use the most forward position for big children



Extra Side Impact Protection



There are SIP pods on each side of the backrest.

When the booster seat is installed in an outboard position the SIP pod closest to the door can be extended to keep the booster further away from the door in an impact.

To extend simply pull the pod out.

To retract push the button in.

Do not extend the pod on the side facing into the vehicle or when the booster seat is installed in the centre seating position.



Removing and Refitting Cover


Seat Pad

Remove the Cup Holder. Release the bottom edges of the seat pad by releasing the 6 snaps and remove.



Seat Back

Release the 2 snaps at the lower back, unhook the 4 elastic bands on the back side and remove the cover by lifting it over the headrest.



Headrest

Raise to highest position, unhook 4 elastic bands and remove. Start by pulling the top edge forwards.

To refit the cover reverse the steps above.

VERY IMPORTANT:
Only replace the cover with a manufacturer's supplied replacement cover with identical shoulder height markers or a replacement cover meeting AS/NZS 8005.

Fitting and Removing Cupholder



To fit: insert cupholder clip through opening in cover and into matching slot in the base.

To remove: hold cupholder firmly and pull upwards.

IMPORTANT: the cupholder must be securely fitted into the slot in the base or it may dislodge.

Do not place heavy or sharp objects in the cupholder.

NEVER PLACE CONTAINERS WITH HOT LIQUIDS IN THE CUPHOLDER.



Care, Maintenance and Storage

Seat Cover

Wash with warm water (under 30°C) and mild detergent.

Do not iron.

Do not bleach or dry clean.

Do not twist the soft goods to dry with great force. It may leave the seat cover with wrinkles.

Hang dry the seat cover in the shade.

Plastic and Metal Parts

Use only mild detergent, water and a soft cloth to clean the car seat shell, handle and harness straps. Air dry.

Do not use undiluted detergent, or other solvents to clean - these may cause damage.

Top Tether Straps

Either spot clean or replace.

Do not immerse the top tether strap in water.

Storage

Remove the booster seat from the vehicle seat if not in use for a long period of time.

Store the booster seat in a cool, dry place where your child cannot access it.

Accessories and Spare Parts

Accessories

DO NOT add accessories, toys, padding or other items to the child restraint unless provided by Nuna.

Aftermarket accessories (i.e. items not provided in the box with the child restraint), may not have been tested for use with this child restraint and if used, may lower the level of protection offered possibly leading to injury or death.

Any aftermarket accessory used should be compliant with AS/NZS 8005 (Accessories for child restraints for use in motor vehicles) and stated as suitable for use with this child restraint.

Spare Parts

If spare parts are required contact the retail outlet from where the restraint was purchased or contact the Australian distributor for the location of your nearest repair agent.

Repairs must only be done by an approved repair agent.