



重要! 請詳細閱讀並保留以備參照!


使用產品前請仔細閱讀說明書，
並妥善保存說明書以便日後參考。



1



4
1
2
2



2



5
1
1



3
1
2
click



6
2



7
click


10



8
click


11



9
2
1
1


12


13




16




19




22




14




17




20




23




15




18




21




24




25




28




31




34




26




29




32



35




27




30





33





36






37



40



38
click



41
R
L



39
click



42



43


46



44


47


45
1
2
1
2


48


49




52



50



51



繁中

Designed
around your life

nuna®

目錄

產品資訊 2
- 保固與售後服務
- 保固條件

適用範圍 3
警告 4
產品組件及各部位名稱 10
安裝手推車 12
產品使用 13
使用配件 15
維護與保養 17

English 18

產品資訊

產品名稱：_____

生產日期：_____

保固與售後服務

產品於保固期間內發生問題，請與零售商聯絡；若零售商無法提供服務，他們會聯絡當地的Nuna經銷商。產品在正常使用和老化中產生的自然磨損與劣化，並不在保固範圍內。當車輪磨損過度時，請向本公司或代理商聯繫更換(需支付費用)。
請留意產品底部的產品型號與生產日期序號。

當有保固需求時，請提供以上產品資訊。
請至www.nunababy.com/tw/gear-registration網站登記您購買的產品。

保固條件

保固始於產品購買日，我們提供維修服務，但不提供產品退換。保固期限不會因零件更換或維修而延長。Nuna有權利針對產品進行改善設計，此前製造的產品則無更換義務。相關保固資訊，詳見官網：www.nunababy.com/tw/warranty

產品名稱	手推嬰幼兒車
型　　號	SWIV
主要材質	塑膠、鋁合金／五金、布
原 產 地	中國
製造年份	請見產品上生產日期標(年／月／日)

注意事項及緊急處理方法：
使用本產品時，請詳閱使用說明書及注意事項。
發生意外時，應盡速就醫急救。

適用範圍

寶寶需要滿足下列要求
最大體重：22公斤
嬰幼兒年齡：0-48個月
當與NUNA汽車椅配合使用，適用範圍請參見該產品說明書。

警告

Nuna SWIV手推嬰幼兒車擁有專利並符合臺灣標準 CNS 12940-2:2022 和歐盟安全標準 EN 1888-2:2018+A1:2022 相關規範。

重要：請務必依照產品說明書和警告以避免導致嚴重傷害甚至是死亡事件發生。

- ! 嬰幼兒的安全是您的責任。
- ! 為避免手指夾傷問題，收合及展開手推嬰兒車時，請務必小心。
- ! 切勿讓嬰幼兒單獨留在手推車內而無人看護。
- ! 請保留說明書以便日後使用。
- ! 六個月大以下的嬰幼兒應同時使用腰部及胯部的安全帶。
- ! 寶寶乘坐時，安全帶或束縛系統必須正確的扣合及使用。
- ! 使用前，請確保座椅或汽車椅等裝置正確安裝。
- ! 請勿允許您的嬰幼兒將手推車當玩具玩耍。
- ! 使用前，請確保所有鎖定裝置都已處於鎖定狀態。
- ! 本產品不適用於跑步和滑冰。
- ! 當調整手推車上之任何可活動配件時，必須確定寶寶與手推車保持安全距離。
- ! 保持寶寶遠離遮陽篷/雨篷以免造成窒息。
- ! 請使用Nuna原廠零配件。
- ! 使用前請確定各部件安裝牢固以確保安全。
- ! 停止車台時，手推車務必確實使用制動裝置。
- ! Nuna不保固使用其它廠商提供的零配件所造成的損害。
- ! 任意放置未經製造商核可之物品於車臺上將造成危險。
- ! 不得附載其它的嬰幼兒、物品或附件於推車上。
- ! 不可將手推車放置於馬路、坡道或危險場所。
- ! 寶寶乘坐於手推車內時，不可將整個手推車往上提。
- ! 使用時請扣好安全帶，以免寶寶滑入腿部開口外而造成窒息。
- ! 使用時請遠離火源、高溫、水池或電源之附近範圍。
- ! 請勿在遮陽篷上放置任何物品。
- ! 請勿將產品放置潮濕的環境中。請自然風乾手推車上的布料，並避免使用直接熱源烘乾。
- ! 請勿將嬰幼兒放到置物籃內。
- ! 如果有任何零件損壞，磨破或丟失，請停止使用該產品。

- 當嬰幼兒需睡眠時，請將之放置於合適的嬰兒床。
- 為避免窒息危險，請將小零件存放到嬰幼兒接觸不到的地方。
- 請注意在粗糙地面使用時，反復衝擊會損壞手推嬰兒車。
- 不可讓嬰幼兒站立。
- 一次僅能乘坐一位嬰幼兒。
- 禁止在樓梯上使用手推車。
- 安全帶或束縛系統必須正確的扣合及使用。且安全帶與束縛系統的使用，不能取代成人的看護。
- 嬰幼兒放入或抱出手推車時，務必確認剎車已處於鎖定狀態。
- 此手推車適用於新生-22公斤嬰幼兒使用。
- 使用前應確實豎立及固定各機構以確保安全。
- 超載、不正確的收合、使用非經核准的零配件都可能造成手推嬰兒車損壞、故障或不安全，請務必閱讀說明書。
- 輪胎可能會在某些表面留下黑色痕跡，特別是光滑的表面，像木地板、合層板和亞麻油地板。
- 請勿將任何繩索或索帶類物件懸掛於嬰幼兒頸部附近，或扣在產品及玩具上，以免導致嬰幼兒意外窒息。

- 使用手推車之前，請務必去掉、銷毀或是將所有附加包裝遠離嬰幼兒，以防嬰幼兒窒息。
- 請勿擺放超過10公斤的物件於置物籃以及0.45公斤的物件於置物口袋內，以免導致手推車不穩定而產生危險。
- 置物杯的最大載重為0.45公斤。
- 乘載超過22公斤的重量，將會導致手推車的重度磨損以及過重的負荷。
- 供新生兒使用時，應使用最斜躺位置。
- 當結合汽車椅使用時，本產品不可代替睡床使用。若您的寶寶需要睡眠時，請讓寶寶睡在合適的睡床上。
- 避免燙傷兒童，請勿將熱飲放入置物杯內。
- 安全帶扣具組含有磁鐵，會影響某些醫療器材的運作。若您的孩子有使用這類醫療器材，禁止磁鐵靠近孩子與醫療器材，請勿使用此推車。請與Nuna聯繫進一步討論方案。
- 請注意安全帶扣具組中的磁鐵可能與某些電子設備產生作用。
- 切勿留置嬰幼兒無人照顧。
- 使用前，確保所有鎖定裝置皆已嚙合。
- 為避免傷害，確保展開與折疊本產品時與兒童保持距離。

- ! 不要讓兒童玩弄本產品。
- ! 務必隨時使用束縛系統。
- ! 本產品僅設計供步行使用。
- ! 為防止事故發生，確保手推嬰幼兒車遠離自動閉合之門 (例：在火車或電梯上)。
- ! 放置與抱起嬰幼兒時，嚙合駐車裝置。
- ! 把手及/或靠背後方及/或手推嬰幼兒車側面的任何掛載將會影響手推嬰幼兒車穩定性。
- ! 未經製造商認可附件不得使用。
- ! 僅限使用製造商/經銷商所提供或建議的替換零件。
- ! 本商品不可放置於機車踏墊使用，亦不可以連結器連接其他手推嬰幼兒車使用。
- ! 使用前查核座椅單元或汽車安全座椅之連接裝置是否正確嚙合。


Note

產品組件及各部位名稱

組裝前請確認所有部件已經齊全。如有遺漏，請與銷售商聯繫。本產品無需工具進行組裝。

! 窒息危險：務必去掉、丟棄每個車輪或輪軸的保護套。

1 扶手
2 連接器卡座
3 遮陽篷
4 扶手
5 小座墊
6 座墊
7 前輪
8 肩帶護片
9 安全扣
10 座椅卡合按鈕
11 小腿靠調整按鈕
12 置物籃
13 定位器口袋
14 小座墊
15 置物杯
16 漂移按鈕
17 車手調整按鈕
18 座椅收合按鈕
(背靠調整按鈕的中間)
19 背靠調整按鈕
20 置物口袋
(最大載重=0.45kg)
21 收合織帶(座椅下面)
22 剎車踏板
23 後輪
24 雨篷
25 置物袋



安裝手推車

打開手推車

1 - 取出手推車架**(1)**

2 - 向上拉起車手以打開手推車架**(2)**

3 - 將座椅打開**(3)-1**，向下按壓座椅的中間位置**(3)-2**

! 聽到**“咔噠”**聲表示座椅已完全打開。

! 使用手推車前請務必確保車架已打開到位。

小座墊

安裝小座墊，請將小座墊置於座椅並將肩帶、腰帶及胯帶護片從小座墊的對應孔穿出**(4)**

座椅換向

1 - 按下座椅卡合按鈕**(5)**並提起座椅**(6)**

2 - 將座椅換向後接合於車架**(7)**聽到**“咔噠”**聲表示座椅已完成接合。

! 當手推車停止前進時，當放入和移除寶寶時，必須踩下剎車踏板。

安裝扶手

! 建議始終使用扶手，但扶手並不能確保寶寶的安全。寶寶乘坐時必須繫上安全帶。

1 - 將扶手卡槽對準扶手座插入，聽到**“咔噠”**聲表示扶手已安裝完成**(8)**

2 - 按壓扶手兩側釋鎖按鈕**(9)-1**，兩側同時向外拉即可拆卸扶手**(9)-2**

產品使用

繁中

使用遮陽篷

! 使用前請移除遮陽篷天窗BMW飾釦上的膠膜。

1 - 打開遮陽篷，請將遮陽篷推向前方。折疊遮陽篷，請將遮陽篷拉向後方**(10)**

2 - 遮陽篷中段拉鍊可打開以延伸遮陽篷範圍**(11)**

3 - 遮陽篷天窗可打開增加透氣性**(12)**

調整小腿靠

小腿靠共有兩種角度可供調節。

1 - 段位調高時，將小腿靠支撐板由下往上推即可**(13)**

2 - 段位調低時，按壓小腿靠兩側的調整按鈕，同時向下調節小腿靠支撐板**(14)**

調整背靠

背靠可3段角度調節。供新生兒使用時，應使用最斜躺位置。

1 - 調高或調低背靠角度，請按壓背靠調整按鈕**(15)-1**，向上或向下調整至所需的背靠角度**(15)-2**

! 調整背靠高度時，請勿按壓**(16)**位於背靠調整按鈕中央的按鈕，請確保使用合適的背靠角度。

使用剎車

1 - 準備剎車時，踩下剎車踏板**(17)**

2 - 打開剎車時，將剎車踏板抬起**(18)**

! 手推車停止時，請剎車。
輕輕推動推車以確保剎車裝置已啟動。

使用儲物袋

1 - 較輕的物體可以儲存在座椅背後的儲物袋裏面**(19)**

! 為防止出現危險、不穩定的情況，不要在儲物袋裏放置超過0.45kg的物品。

使用飄移功能

1 - 按壓飄移按鈕，手推車可以四輪旋轉**(20)**

! 使用飄移功能後，請務必將手推車向前推行一段距離，使輪子恢復到鎖定狀態，方可正常使用。

使用安全扣

1 - 按下母扣上方的按鈕，安全扣會自動鬆開**(21)**，將寶寶放入手推車。

2 - 將肩帶及腰部扣環與母扣結合**(22)**

3 - 滑動織帶(在肩帶護片下方)調整織帶長度**(23)-1**，拉緊腰部織帶**(23)-2**，使寶寶更加舒適。

調整肩帶位置

1 - 肩帶固定栓可上下滑動調整至適當位置**(24)**

! 為避免寶寶滑出手推嬰兒車而導致的嚴重傷害，請隨時使用安全帶。

請確保安全帶已適當調整，寶寶與安全帶間的空隙約為一隻手指寬。請勿交叉肩帶以免造成孩童頸部壓力。

使用肩帶護片和胯帶護片

1 - 肩帶護片和胯帶護片可從織帶上取下**(25)**

! 反之即可組裝肩帶護片和胯帶護片

調整車手

! 車手共有3種段位可供使用。

1 - 調整車手，同時按壓車手左右調整按鈕並將車手旋轉至合適的位置**(26)**

2 - 收合手推車前，請將車手調整到第2段位。手推車收合後可站立**(27)**

定位器口袋

1 - 將定位器(定位器需另行購買)放入置物籃的口袋中**(28)**

收合手推車

與座椅連接

! 收攏遮陽篷

1 - 按壓背靠調整鈕中間的座椅收合鈕，並按壓背靠調整鈕**(29)**

2 - 折疊座椅**(30)(31)**

3 - 拉起收合織帶，收合手推車**(32)(33)**

4 - 手推車收合後可站立**(34)(35)**

不與座椅連接

1 - 收合無安裝座椅的手推車時，按壓椅座的收合鈕**(36)**

2 - 手推車車架收合後可站立**(37)**

使用配件

連接器卡座

當與Nuna汽車椅配合使用時，組裝及使用方式請參照該產品說明書。

1 - 安裝連接器卡座，放置卡座於座椅底座上。
聽到“**咔噠**”聲表示卡座已安裝完成**(38)**

2 - 安裝汽車椅，放置於卡座上，聽到“**咔噠**”聲表示已卡合到位**(39)**

3 - 汽車椅角度可以通過可調整的卡座進行調整**(40)**

4 - 連接器卡座上的L與車架釋鎖按鈕上的L相對應，汽車椅連接器卡座後向安裝**(41)(42)**

5 - 移除汽車椅，按壓汽車椅釋鎖按鈕**(43)**，同時向上提起汽車椅即可**(44)**

6 - 移除連接器卡座，按壓卡座的釋鎖鈕**(45)-1**，並向上提起連接器卡座**(45)-2**

使用連接器卡座的收合方式

1 - 拉起連接器卡座上的收合織帶以收合手推車**(46)**

置物杯

1 - 將置物杯固定裝置固定於手推車車手，位於皮革手把的下方**(47)**

2 - 旋轉固定裝置到車手上**(48)**

3 - 扣合固定裝置**(49)**，聽到“**咔噠**”聲表明置物杯已連接穩固。

4 - 拆除置物杯，將固定裝置打開，然後將置物杯從車手上移除**(50)**

! 收合嬰兒車前請移除置物杯。

置物袋

1 - 將收合的嬰兒車放置在置物袋裏，輪子在置物袋底部，並拉緊拉繩把置物袋收起來。置物袋可以使用背帶提攜**(51)**

雨篷

安裝雨篷前，請確認雨篷已完全展開。

1 - 將雨篷套到座椅上**(52)**

! 使用雨篷時，請隨時注意並確認雨篷內有良好的通風。

! 不使用雨篷時，請先確認雨篷已清潔並乾燥，再收納。

! 請勿收合已罩上雨篷的手推車。

! 天氣炎熱時，請勿將寶寶放在裝有雨篷的手推車內。

維修與保養

可用濕布清潔車架和座布，請勿使用研磨劑或漂白劑。請勿使用潤滑劑，因為它們會吸附灰塵和污垢。請勿將手推車儲存在潮濕的地方。

請定期以水清洗輪子，並清除污垢。

為使手推車能長期使用，下雨天使用後，請用軟質可吸水的布擦拭手推車。

請參考手推車上洗滌標的洗滌方式。

長期使用之後，在正常狀況下，座布可能產生褪色、磨損或撕裂。

為確保安全，請使用Nuna原廠零配件。

請定期檢查您的手推車功能是否正常與零件是否鬆弛磨損或脫落。一旦發生以上任何狀況，請立即停止使用本手推車。

請隨時檢查束縛系統的日字扣，扣具和整個安全帶(包括任何點)是否完好無損。

如有任何磨損，裂紋或破損情況。請立即停止使用。

NUNA International B.V. Nuna及所有相關徽標皆為商標

IMPORTANT!
READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

EN

Contents

Product Information 20
Product Registration
Warranty
Child Usage Requirements 20
Warnings 21
Parts List 24
Product Set Up 26
Product Use 27
Accessories 30
Cleaning and Maintenance 32

Product Information

Model Number:_____

Manufactured Date:_____

Product Registration

Please fill in the above information. The model number and the manufactured date are located on a label on the stroller frame.

To register your product please visit:
www.nunababy.com
Click the “Register Gear” link on the homepage.

Warranty

We have purposely designed our high-quality products so that they can grow with both your child and your family. Because we stand by our product, our gear is covered by a custom warranty per product, starting from the day it was purchased. Please have the proof of purchase, model number and manufactured date available when you contact us.

For warranty information please visit:
www.nunababy.com
Click the “Warranty” link on the homepage.

Child Usage Requirements

This stroller seat is suitable for use with children who meet the following requirements:

Birth to 22 kg or 4 years whichever comes first

When using the stroller frame with NUNA infant carrier, refer to the child usage requirements listed in the infant carrier instruction manual.

⚠WARNING

Failure to follow these warnings and instructions could result in serious injury or death.

Always use the restraint system.

Check that the seat unit or car seat attachment devices are correctly engaged before use.

Do not let the child play with this product.

Ensure that all the locking devices are engaged before use.

Never leave the child unattended.

This product is not suitable for running or skating.

To avoid injury ensure that the child is kept away when unfolding and folding this product.

Accessories which are not approved by the manufacturer shall not be used. Only replacement parts supplied or recommended by the manufacturer/distributor shall be used.

Adult assembly required.

Any load attached to the handle and/or on the back of the backrest and/or on the sides of the vehicle will affect the stability of the vehicle.

DO NOT carry additional children, goods, accessories in or on the stroller except as permitted in this manual. They may cause the stroller to become unstable.

DO NOT leave the stroller exposed in the vicinity of a strong source of heat i.e. a radiator or open fire.

DO NOT place any item on the canopy.

DO NOT store the stroller in a damp place. Always allow the fabric to dry naturally away from direct heat.

DO NOT use storage basket as a child carrier.

DO NOT use the stroller if any parts are damaged or missing.

For car seats used in conjunction with a chassis, this vehicle does not replace a cot or a bed. Should your child need to sleep, then it should be placed in a suitable bed.

Keep small parts away from children as they pose a choking hazard.

Negotiate curbs and rough ground carefully. Repeated impact could cause damage to the stroller.

The parking device shall be engaged when placing and removing the children.

NEVER allow children to stand on the stroller.

NEVER use the stroller on stairs or escalators. You may suddenly lose control of the stroller or your child may fall out.

NEVER carry more than one child at a time in the stroller.

Overloading, incorrect folding, and the use of accessories e.g. child seats, bag hooks, rain covers, buggy boards, etc… other than those approved by Nuna may damage or make the stroller unsafe.

STRANGULATION HAZARD Do not place items with a string around your child's neck, suspend strings from this product, or attach strings to toys.

To avoid any danger of suffocation, remove all plastic covers before using this item and destroy or keep away from babies and children!

To prevent a hazardous, unstable condition, do not place more than 10 kg in the storage basket and more than 0.45 kg in the storage pocket.

To prevent a hazardous, unstable condition, do not place more than 0.45 kg in the cup holder.

ALWAYS check ventilation when the rain cover is on the product.

ALWAYS check that the rain cover has been cleaned and dried before folding.

DO NOT fold the pushchair when the rain cover is attached.

DO NOT place your child in the pushchair in hot weather with the rain cover attached.

Make sure the harness is adjusted properly and your child is snugly secured. The space between the child and the shoulder harness should be about the thickness of one finger. **DO NOT** cross the shoulder belts. This will cause pressure on your child's neck.

USE the most reclined position for new born babies.

To avoid burns, never put hot liquids in your cupholder.

Magnetic Harness Buckle: The buckle and buckle clips contain magnets. If your child has a medical condition that prohibits the use of magnets near the child, do not use the stroller. Contact Nuna to discuss a solution.


Be mindful of the possible interaction of magnets in buckles and certain electronic devices.

Parts List

Make sure all parts are available before assembly.
If any part is missing, please contact local retailer. No tools are required for assembly.

! **CHOKING HAZARD:** Remove and immediately discard protective end caps from each wheel and wheel hub axle.

1 Arm Bar
2 Adapter
3 Canopy
4 Arm Bar
5 Insert
6 Seat Pad
7 Front Wheel
8 Shoulder Harness Pad
9 Buckle
10 Seat Release Button
11 Calf Support Adjustment Button
12 Storage Basket
13 Tracking Device Pocket
14 Insert
15 Cup Holder
16 Drift Button
17 Handle Button
18 Fold Button (in the middle of the Recline Adjustment Button)
19 Recline Adjustment Button
20 Storage Pocket
21 Stroller Fold Strap (under the seat)
22 Brake Lever
23 Rear Wheel
24 Rain Cover
25 Travel Bag



EN

Product Set Up

Open Stroller

1 - Take the stroller frame out. **(1)**

2 - Rotate the handle up to open the stroller frame. **(2)**

3 - Pull the seat to open it **(3)-1** and press the middle of seat down **(3)-2.**

! A **“click”** sound means the stroller frame is open.

! Check that the stroller is completely latched open before continuing.

Insert

1 - To assemble the insert, place the insert over the seat and thread the shoulder, waist and crotch harnesses through their respective slots. **(4)**

Reverse Seat

1 - Press the seat release button **(5)** and lift the seat up **(6).**

2 - Reverse the seat, and then attach it to the frame. **(7)**

A **“click”** sound means the seat is attached completely.

! The parking brake **MUST** be engaged when the stroller is stopped and when placing and removing child.

Arm Bar

! It is always recommended that the arm bar be used, but it is not a restraint device. Always secure the child with the harness.

1 - Align the arm bar ends with the arm bar mounts, and insert until it clicks into place. A **“click”** sound means the arm bar is assembled completely. **(8)**

2 - To remove the arm bar, press the arm bar release buttons **(9)-1** and lift the arm bar up **(9)-2.**

Product Use

Canopy

! Before using the stroller, peel off the protective film covering the BMW logo button located on the rear canopy panel.

1 - To open the canopy, pull the canopy toward the front of the seat. To close the canopy, push it back. **(10)**

2 - Unzip the zipper for extra shade. **(11)**

3 - For added ventilation, flip the canopy window cover up. **(12)**

Calf Support

The calf support has 2 use positions.

1 - To raise the calf support, lift up. **(13)**

2 - To lower the calf support, press the adjustment button, and push down. **(14)**

Recline

There are 3 recline positions for the backrest. USE the most reclined position for new born babies.

1 - To raise or lower the backrest, squeeze the recline adjustment button **(15)-1**, and pull the backrest up or down **(15)-2.**

! Please do not press the button **(16)** on the middle of the recline adjustment button when adjusting the angle for the recline.

Brake

1 - To lock wheels, step the brake lever downwards. **(17)**

2 - To release wheels, just lift the brake lever upwards. **(18)**

Storage Pocket

1 - Use the storage pocket on the back of the seat for lightweight storage. **(19)**

! To prevent a hazardous, unstable condition, **DO NOT** place more than 0.45 kg of items in the storage pocket.

Use Drift

1 - Press the drift button, All wheels of the stroller can be rotated. **(20)**

! Please be sure to push the stroller forward for a distance to make wheels return to locked state after use drift, then stroller can be used normally.

Securing Your Child

1 - Push the top button on the buckle to release the buckle latch and remove the magnetic clips. **(21)**

Place your child in the stroller.

2 - Insert the magnetic clips into the buckle. **(22)**

3 - Fit the harness snugly to your child by sliding the adjustment straps to tighten **(23)-1**. Then pull the waist adjustment straps out. **(23)-2**

Shoulder Harness Position

1 - The upper shoulder harness buckles can be moved up and down for added adjustment. **(24)**

! To avoid serious injury from falling or sliding out, always secure your child with the harness.

Make sure the harness is adjusted properly and your child is snugly secured. The space between the child and the shoulder harness should be about the thickness of one finger.

DO NOT cross the shoulder belts. This will cause pressure on child's neck.

Shoulder Harness Cover and Crotch Harness Cover

1 - The shoulder harness cover & crotch harness cover can be removed from the webbing. **(25)**

! To assemble shoulder harness cover and crotch harness cover in reverse steps.

Adjust Handle

! Handle can be adjusted to 3 positions.

1 - To adjust the handle, press the left and right handle adjustment buttons at the same time, and rotate the handle to a desirable position. **(26)**

2 - Before folding the stroller, please adjust the handle to the second position. The stroller can stand after folding. **(27)**

Tracking Device Pocket

1 - Insert tracking device (tracking device not included) into pocket in basket. **(28)**

Fold

With Seat Attached

! Close the canopy.

1 - Press the fold button on the middle of the recline adjustment button, then pull the recline adjustment button. **(29)**

2 - Fold the seat down. **(30)(31)**

3 - Pull the stroller fold strap to fold the stroller. **(32)(33)**

4 - The stroller can stand after folded. **(34)(35)**

Without Seat Attached

1 - Fold the stroller without seat on it, press the folding buttons of the seat mounts. **(36)**

2 - The stroller frame can stand after folded. **(37)**

Accessories

Post Adaptors

For Nuna infant carrier assembly and usage, please refer to the infant carrier instruction manual.

1 - To attach the post adapters, place the post adapters on the seat mounts. A **"click"** sound means the post adapters are attached. **(38)**

2 - To attach infant carrier, place the infant carrier on the post adapters. A **"click"** sound means the infant carrier is attached. **(39)**

3 - The infant carrier angle can be adjusted with our adjustable adaptors. **(40)**

4 - The letters on the post adaptors are the same as those on the frame plastic. **(41) (42)**

5 - To remove the infant carrier, push the release buttons on the infant carrier **(43)** and lift up **(44).**

6 - To remove the post adapters, press the adapter release buttons **(45)-1** and lift up **(45)-2.**

Fold the Stroller with Post Adapters

1 - Pull the folding webbing of the post adapters to fold the stroller. **(46)**

Cup Holder

1 - To attach the cup holder, secure the right side of the cup holder clamp around the stroller handle, handle just below the leatherette pushbar. **(47)**

2 - Rotate the left side of the clamp over the pushbar handle. **(48)**

3 - Push the two pieces of the clamp together and listen for a **"click"**. A **"click"** sound means the cup holder is securely attached. **(49)**

4 - To remove the cup holder, push apart the two pieces of the clamp and remove the cup holder from the pushbar **(50)**.

! Remove the cup holder before folding the stroller.

Travel Bag

1 - Place the folded stroller into the bag with the wheels at the bottom, and close the bag by tightening the drawstring. The bag can be carried by the carry strap. **(51)**

Rain Cover

1 - To assemble the rain cover, place it over the stroller. **(52)**

! **ALWAYS** check ventilation when the rain cover is on the product.

! **ALWAYS** check that the rain cover has been cleaned and dried before folding.

! **DO NOT** fold the stroller with the rain cover in place.

! **DO NOT** place your child into the stroller with the rain cover in place during hot weather.

EN

Cleaning and Maintenance

Clean the frame, plastic parts, and fabric with a damp cloth, but do not use abrasives or bleach. Do not use silicon lubricants as they will attract dirt and grime. Do not store your stroller in a damp place.

Clean the stroller wheels regularly with water and remove any dirt.

To ensure long-lasting use, wipe the stroller off with a soft, absorbent cloth after using it in rainy weather.

Refer to the care label attached to the soft goods for washing and drying instructions.

It is normal for fabric to color from sunlight and to show wear and tear after a long period of use, even when used normally.

For reasons of safety, only use original Nuna parts.

Check regularly if everything functions properly. If any parts are torn, broken, or missing, stop using this product.

NUNA International B.V. Nuna and all associated logos are trademarks.